TurboDriver
Printers Supplement

Hewlett-Packard printers
(DeskJet & LaserJet)

also suitable for the Acorn JP-150
& Integrex ColourJet Series 2

What the discs contain:

Disc 1:

!Install – the installer program. Page 5 of the TurboDriver manual describes using this.
ReadMe – this just repeats installation information.
ImageExtnd – this is required if you have Computer Concepts' ScanLight application. (See page 7 of the TurboDriver manual.)
PrintDefns – a directory of printer definitions. The Installation information (see below) contains a list of the definitions and which printers they are suitable for.
TestPrints – four-colour TestFile (*4ColTest*) and *HeadTest*. Page 6 of the TurboDriver manual describes using these files. There is information on four-colour printing on the back page of this supplement.

Disc 2:

TestPrints – monochrome (*MonoTest*) and three-colour (*3ColTest*) TestFiles. Page 6 of the TurboDriver manual describes using these files.

Installation information

Switch settings

Set the paper size to A4. Refer to your printer manual for details of which switch sets the paper size. The other switches have no effect on TurboDriver.

Printer definitions

These are in the *PrintDefns* directory on disc 1. Make sure you use the correct printer definition for your type of printer:

black-and-white DeskJet printers	DeskJet
DJ500C	DJ500c
DJ550C	DJ550c
DJ1200	DJ550c
LaserJet 2	LJ-II
LaserJet 3	LJ-III
LaserJet 4	LJ-IVm
Acorn JP-150	DeskJet
Integrex ColourJet Series 2	DJ500c

Paper sizes

Use *Generic DeskJet* sizes for DeskJet (DJ), Acorn & Integrex printers.

Use *Generic LJ* sizes for LaserJet printers.

General information

Pamphlet printing in Impression

Pamphlet printing is described in the Impression manual.

On Impression's Print Setup dialogue box set the **Reverse** switch to **off**. The **Ignore page border** option should be **off**. If you want to print several copies of a multi-page pamphlet, you can set the **Collated** switch to print the pages in sequence (1,2,3..., 1,2,3...). This saves the chore of collating the sheets afterwards but is slower than printing all the copies of the first page, then all the copies of the second page and so on.

The message to turn over the paper will appear before TurboDriver has finished printing all the sheets. Wait until printing has finished.

Printing "unknown" file types

There is a problem when you drop a file directly onto the printer icon and either:

- the file is of a type not not normally printed, such as a module, or
- the filetype is unrecognised by the operating system. (The operating system recognises most common filetypes such as Draw, Edit, and Sprites.)

In this situation, *!Printers* displays a dialogue box which follows the mouse pointer around the screen. You can usually print the file as Plain text or Fancy text. Clicking on Cancel can cause *Printers* to abort. (This part of the software was written by Acorn Computers, not by Computer Concepts.)

Information on specific printers

Four-colour printers (DJ550C & DJ1200)

We have extensively tested these and cannot get satisfactory results printing pictures using all four inks. The black ink always runs when printed close to the other colours. For this reason we recommend:

- Use **Four-colour** when printing mainly text or black-and-white pictures.
- Use **Three-colour** when printing coloured pictures.

The problem is caused by differing ink formulations. It is **not** a TurboDriver problem.

©1993 Computer Concepts Ltd.